

L1497 Rev. C 03/03

Repair Parts Sheets for this product are available from the Enerpac web site at [www.enerpac.com](http://www.enerpac.com), or from your nearest Authorized Enerpac Service Center or Enerpac Sales office.

#### 1.0 IMPORTANT RECEIVING INSTRUCTIONS

Visually inspect all components for shipping damage. Shipping damage is not covered by warranty. If shipping damage is found, notify carrier at once. The carrier is responsible for all repair and replacement costs resulting from damage in shipment.

#### SAFETY FIRST

#### 2.0 SAFETY ISSUES



Read all instructions, warnings and cautions carefully. Follow all safety precautions to avoid personal injury or property damage during system operation. Enerpac cannot be responsible for damage or injury resulting from unsafe product use, lack of maintenance or incorrect product and/or system operation. Contact Enerpac when in doubt as to the safety precautions and operations. If you have never been trained on high-pressure hydraulic safety, consult your distribution or service center for a free Enerpac Hydraulic safety course.

Failure to comply with the following cautions and warnings could cause equipment damage and personal injury.

A **CAUTION** is used to indicate correct operating or maintenance procedures and practices to prevent damage to, or destruction of equipment or other property.

A **WARNING** indicates a potential danger that requires correct procedures or practices to avoid personal injury.

A **DANGER** is only used when your action or lack of action may cause serious injury or even death.



**WARNING:** Wear proper personal protective gear when operating hydraulic equipment.



**WARNING: Stay clear of loads supported by hydraulics.** A cylinder, when used as a load lifting device, should never be used as a load holding device. After the load has been raised or lowered, it must always be blocked mechanically.



**DANGER:** To avoid personal injury keep hands and feet away from cylinder and workpiece during operation.



**WARNING:** Do not exceed equipment ratings. Never attempt to lift a load weighing more than the capacity of the cylinder. Overloading causes equipment failure and possible personal injury. The cylinders are designed for a max. pressure of 350 bar [5,000 psi]. Do not connect a jack or cylinder to a pump with a higher pressure rating.



**Never** set the relief valve to a higher pressure than the maximum rated pressure of the pump. Higher settings may result in equipment damage and/or personal injury.

WA-502 Accumulator



**WARNING:** The system operating pressure must not exceed the pressure rating of the lowest rated component in the system. Install pressure gauges in the system to monitor operating pressure. It is your window to what is happening in the system.



**CAUTION:** Avoid damaging hydraulic hose. Avoid sharp bends and kinks when routing hydraulic hoses. Using a bent or kinked hose will cause severe back-pressure. Sharp bends and kinks will internally damage the hose leading to premature hose failure.



**Do not** drop heavy objects on hose. A sharp impact may cause internal damage to hose wire strands. Applying pressure to a damaged hose may cause it to rupture.



**IMPORTANT:** Do not lift hydraulic equipment by the hoses or swivel couplers. Use the carrying handle or other means of safe transport.



**CAUTION: Keep hydraulic equipment away from flames and heat.** Excessive heat will soften packings and seals, resulting in fluid leaks. Heat also weakens hose materials and packings. For optimum performance do not expose equipment to temperatures of 65 °C [150 °F] or higher. Protect hoses and cylinders from weld spatter.



**DANGER: Do not handle pressurized hoses.** Escaping oil under pressure can penetrate the skin, causing serious injury. If oil is injected under the skin, see a doctor immediately.



**WARNING:** Only use hydraulic cylinders in a coupled system. Never use a cylinder with unconnected couplers. If the cylinder becomes extremely overloaded, components can fail catastrophically causing severe personal injury.



**IMPORTANT:** Hydraulic equipment must only be serviced by a qualified hydraulic technician. For repair service, contact the Authorized ENERPAC Service Center in your area. To protect your warranty, use only ENERPAC oil.



**WARNING:** Immediately replace worn or damaged parts by genuine ENERPAC parts. Standard grade parts will break causing personal injury and property damage. ENERPAC parts are designed to fit properly and withstand high loads.



**CAUTION:** To avoid internal seal damage, use only Enerpac hydraulic oil in the accumulator oil chamber. Seals are not designed for water or other liquids.



**WARNING:** Maximum charge of the accumulator is 5,000 psi. Do not overcharge the accumulator.



**WARNING:** Use only approved recharging equipment. Recharge using inert gas, such as nitrogen. Follow all charging instructions.



**WARNING:** Prior to performing maintenance on the accumulator or associated hydraulic lines, always discharge hydraulic lines, always discharge hydraulic oil and nitrogen gas.

### 3.0 DESCRIPTION


Accumulators consist of a steel outer casing with two internal chambers. An aluminum piston, using seal rings, separates each chamber and prevents the oil and nitrogen from mixing. The nitrogen chamber has a removable end cap and a filler valve. The hydraulic fluid chamber has a threaded steel end cap with a #8 SAE thread oil port. (See Cross Section in Figure 1).

The accumulator provides hydraulic oil under pressure to the system whenever system operating pressure decreases. The accumulator operates when hydraulic oil is pumped into one chamber forcing the piston to compress the nitrogen gas in the other chamber. When hydraulic pressure decreases, the nitrogen moves the piston, forcing hydraulic fluid into the system.

**NOTE:** Accumulator operating temperature range is -20° to +200°F at a maximum of 5,000 psi.

Accumulators can be used for:

- **Pressure Maintenance** – to compensate for leakage or load-holding without a pump.



**Figure 1**

**Specifications:** This instruction sheet covers four models of Enerpac Accumulators. The following table shows their model numbers, length, and capacity.

Model No.	Length	Nitrogen Capacity	Hydraulic Fluid Capacity
WA-502	4.69 in. (11.91 cm)	2.5 in <sup>3</sup> (40.98 cm <sup>3</sup> )	2.5 in <sup>3</sup> (40.98 cm <sup>3</sup> )
WA-505	5.50 in. (13.97 cm)	5 in <sup>3</sup> (81.95 cm <sup>3</sup> )	5 in <sup>3</sup> (81.95 cm <sup>3</sup> )
WA-5010	7.13 in. (18.11 cm)	10 in <sup>3</sup> (163.90 cm <sup>3</sup> )	10 in <sup>3</sup> (163.90 cm <sup>3</sup> )
WA-5030	13.50 in. (34.29 cm)	30 in <sup>3</sup> (491.70 cm <sup>3</sup> )	30 in <sup>3</sup> (491.70 cm <sup>3</sup> )

- **Supplemental Pump Delivery** – to allow the pump to cycle on and off less frequently.
- **Shock Absorption** – to dampen system pulsations and "water hammer" effects.
- **Limited Power Source** – for emergency, remote, or temporary power.

Contact Enerpac for specific applications and recommendations.

### 4.0 INSTALLATION

#### 4.1 Mounting

1. Mount accumulators between the system hydraulic pump and the working components (i.e. cylinders, clamps, etc.). Standard "U" bolts or AW-50 brackets can be used for mounting.



**CAUTION:** Use care when tightening the mounting brackets so that the outer shell of the accumulator is not damaged or distorted.



**CAUTION:** Mounting devices must not cover the entire shell, thereby restricting normal thermal expansion due to temperature variations.

2. The accumulator may be mounted in any position, provided that the oil line and the charging valve are accessible.
3. Install a shut-off valve in the oil line between the accumulator and the system components to close the oil line from the accumulator, preventing uncontrolled fluid flow.

#### 4.2 Hydraulic Connections



**WARNING:** Do not make or break hydraulic connections when the system is pressurized. Hydraulic oil at 5,000 psi may cause personal injury and/or equipment damage.

The following general guidelines will be helpful in determining if you have properly connected your hydraulic circuit:

- Be sure all hoses and fittings are connected to the proper inlet and outlet ports of the pump and cylinders.
- Be sure all hydraulic connections, hoses, fittings, and couplers are of the proper pressure rating and are fully tightened.
- **Do not** overtighten connections. Connections need only be snug and leak free.
- Seal all NPTF connections with a high-grade pipe thread sealer. If using Teflon tape, use 1-1/2 wraps of tape, leaving the first complete thread free of tape to ensure that pieces do not break off and enter the system, causing damage.

## Precharge Chart

Model Number	Hydraulic Pressure psi (bar)	Pre-charge Pressure psi (bar)	Usable Oil Capacity in <sup>3</sup> (cm <sup>3</sup> )
WA-502	0 - 1,000 (0 - 69)	500 (34)	1.50 at 1,000 psi (25 at 69 bar)
	1,000 - 3,000 (69 - 207)	1,000 (69)	2.00 at 3,000 psi (33 at 207 bar)
	3,000 - 5,000 (207 - 344)	1,000 (69)	2.50 at 5,000 psi (41 at 344 bar)
WA-505	0 - 1,000 (0 - 69)	500 (34)	2.00 at 1,000 psi (33 at 69 bar)
	1,000 - 3,000 (69 - 207)	1,000 (69)	3.50 at 3,000 psi (57 at 207 bar)
	3,000 - 5,000 (207 - 344)	1,200 (83)	4.00 at 5,000 psi (66 at 344 bar)
WA-5010	0 - 1,000 (0 - 69)	500 (34)	5.50 at 1,000 psi (90 at 69 bar)
	1,000 - 3,000 (69 - 207)	1,000 (69)	6.50 at 3,000 psi (107 at 207 bar)
	3,000 - 5,000 (207 - 344)	1,200 (83)	7.50 at 5,000 psi (123 at 344 bar)
WA-5030	0 - 1,000 (0 - 69)	500 (34)	13.50 at 1,000 psi (221 at 69 bar)
	1,000 - 3,000 (69 - 207)	1,000 (69)	18.00 at 3,000 psi (295 at 207 bar)
	3,000 - 5,000 (207 - 344)	1,200 (83)	18.50 at 5,000 (303 at 344 bar)

### 4.3 Pre-charging

Pre-charge is the initial gas pressure that is contained by the accumulator prior to system activation. Typically, pre-charge varies from 30 - 80% of system pressure, depending upon the type of application.

Accumulators are shipped uncharged. When the unit is installed and the hydraulic line is connected, charge the accumulator with nitrogen gas to the required pre-charge pressure. The maximum precharge pressure is 3,000 psi. See the Precharge Chart.

### 4.4 Charging Accumulators

Initial charging and recharging can be accomplished with or without the accumulator installed in the system. When charging an accumulator installed in a system, all hoses and fittings should be inspected to ensure that no leaks exist.

**WARNING:** When charging an accumulator not installed in a system, the hydraulic port should have fittings and plugs removed, and should be directed away from people and equipment, as any residual fluids may be expelled from the accumulator at a high rate of speed.




Figure 2

### Equipment Required

1. Nitrogen tank with gauges and hoses.
2. Enerpac adaptor WAT-1. See Figure 2.

### Conditions Required

1. Hydraulic pump turned "OFF".
2. Shut-off valve between the accumulator and the hydraulic system must be open and free to tank.



**WARNING: Nitrogen gas is recommended for charging accumulators. Never use oxygen or any flammable gas. Never exceed maximum charging pressure of 3,000 psi.**

### Charging Procedure

1. Install the charging adaptor (WAT-1) by removing the protective cap on the accumulator gas fill valve. Slide the hex of the WAT-1 onto the valve while threading the adaptor stem onto the gas fill port hand tight. (See Figure 3).




Figure 3

2. Attach the adaptor stem to the charging regulator on the nitrogen tank. The stem has 1/8 NPTF threads. The regulator must be fully relieved of pressure prior to attaching the adaptor stem.
3. Slowly open the accumulator gas fill valve by turning the WAT-1 adaptor counter-clockwise.

**NOTE:** Bleed down of pressure may occur.

4. While slowly opening the nitrogen tank regulator, charge the accumulator to the desired pressure, not to exceed the maximum of 3,000 psi. Close the accumulator valve by turning the WAT-1 clockwise firmly while it is under pressure.

5. Relieve all pressure to the accumulator using the regulator valve. Remove the WAT-1 adaptor, using caution to avoid opening the gas fill valve on the accumulator. Replace the fill valve protective cap.
6. After removal of the charging tool, the gas fill valve can be tightened to 80 - 100 in-lbs (9.04 - 11.30 Nm). Make certain that the torque wrench socket is engaged on the upper hex of the gas fill valve.
7. Check system performance.

## 5.0 MAINTENANCE AND TROUBLESHOOTING

Normal maintenance consists of replacing the seals using Kit No. WA-500K1. Servicing will be required if deterioration of performance is observed.

Verify that the system is leak free, and that load-holding valves, if used, are functioning properly. If any of the following conditions exist, contact your local Authorized Enerpac Service Center:

1. Frequent recharging of the accumulator is required.
2. Oil is found in the nitrogen chamber.
3. Oil becomes frothy at the hydraulic port of the accumulator.

### Enerpac Worldwide Locations

**Australia**  
ENERPAC, Applied Power  
Australia Ltd.  
Block V Unit 3  
Regents Park Estate  
391 Park Road  
Regents Park NSW 2143  
(P.O. Box 261) Australia  
Tel: +61 297 438 988  
Fax: +61 297 438 648

**Brazil**  
Power Packer do Brasil Ltda.  
Rua dos Inocentes, 587  
04764-050 - Sao Paulo (SP)  
Tel: +55 11 5687 2211  
Fax: +55 11 5686 5583  
**Toll Free in Brazil:**  
Tel: 000 817 200 6718  
vendasbrasil@enerpac.com

**Canada**  
Actuant Canada Corporation  
6615 Ordan Drive, Unit 14-15  
Mississauga, Ontario L5T 1X2  
Tel: +1 905 564 5749  
Fax: +1 905 564 0305  
**Toll Free:**  
Tel: +1 800 268 4987  
Fax: +1 800 461 2456  
**Technical Inquiries:**  
techservices@enerpac.com

**China**  
Actuant China Ltd.  
1F, 269 Fute N. Road  
Waigaoqiao Free Trade Zone  
Pudong New District  
Shanghai, 200 131 China  
Tel: +86 21 5866 9099  
Fax: +86 21 5866 7156

Actuant China Ltd. (Beijing)  
709A Xin No. 2  
Diyang Building  
Dong San Huan North Rd.  
Beijing City, 100028 China  
Tel: +86 10 845 36166  
Fax: +86 10 845 36220

**Eastern Europe**  
Applied Power International S.A.  
Case postale 130  
CH-1213 Onex-Genève  
Switzerland  
Tel: +49 (211) 47149 44  
Fax: +49 (211) 47149 40

**France, Greece, Africa**  
ENERPAC S.A.  
B.P. 200  
Parc d'Activités  
du Moulin de Massy  
F-91882 Massy CEDEX  
(Paris) France  
Tel: +33 1 601 368 68  
Fax: +33 1 692 037 50

**Germany, Austria**  
ENERPAC  
Applied Power GmbH  
P.O. Box 300113  
D-40401 Düsseldorf  
Germany  
Tel: +49 211 471 490  
Fax: +49 211 471 49 28

◆ e-mail: info@enerpac.com

**India**  
ENERPAC Hydraulics  
(India) Pvt. Ltd.  
Plot No. A/571  
MIDC, TTC Industrial Area  
Mahape-400 701  
Navi Mumbai, India  
Tel: +91 22 778 1779  
Fax: +91 22 778 1473

**Italy**  
ENERPAC  
Applied Power Italiana S.p.A.  
Via Canova 4  
20094 Corsico (Milano)  
Tel: +39 02 4861 111  
Fax: +39 02 4860 1288

**Japan**  
Applied Power Japan Ltd.  
1-1-11, Shimomae  
Toda-shi  
Saitama Pref.  
Japan 335-0016  
Tel: +81 48 430 2311  
Fax: +81 48 430 1117

**Mexico**  
ENERPAC Applied Power  
Mexico S. de R.L. de C.V.  
Avenida Principal  
La Paz #100  
Fracc. Industrial La Paz  
42092 Pachuca, Hidalgo  
Tel: +52 771 71851 60  
+52 771 71870 22  
Fax: +52 771 71352 32  
**Toll Free in Mexico:**  
Tel: 001 800 590 0130

**The Netherlands, Belgium,  
Luxembourg, Sweden, Denmark,  
Norway, Finland**  
ENERPAC B.V.  
Storkstraat 25  
P.O. Box 269, 3900 AG Veenendaal  
The Netherlands  
Tel: +31 318 535 911  
Fax: +31 318 525 613  
+31 318 535 848

**Russia and CIS  
(excl. Caspian Sea Countries)**  
ENERPAC  
Leninsky Prospect 95A  
117313, Moscow, Russia.  
Tel/Fax: +7(095) 936-2005  
Tel/Fax: +7(095) 198-3094  
Tel/Fax: +7(095) 938-4655  
Mobil: +7(903) 731-9558

**Singapore**  
Actuant Asia Pte. Ltd.  
25 Serangoon North Ave. 5  
#03-01 Keppel Digihub  
Singapore 554914  
Thomson Road  
P.O. Box 114  
Singapore 915704  
Tel: +65 64 84 5108  
+65 64 84 3737  
Fax: +65 64 84 5669

**South Korea**  
ENERPAC  
Applied Power Korea Ltd.  
163-12 Dodang-Dong  
Wonmi-Ku, Buchun-shi  
Kyunggi-Do  
Republic of Korea  
Tel: +82 32 675 08 36  
Fax: +82 32 675 30 02/73

◆ internet: www.enerpac.com

**Spain, Portugal**  
ENERPAC  
C/San José Artesano 8  
Pol. Ind.  
28108 Alcobendas  
(Madrid) Spain  
Tel: +34 91 661 11 25  
Fax: +34 91 661 47 89

**Middle East, Turkey  
and Caspian Sea**  
ENERPAC Middle East FZE  
P.O. Box 18004  
Jebel Ali, Dubai  
United Arab Emirates  
Tel: +971 (0)4 8872686  
Fax: +971 (0)4 8872687

**United Kingdom, Ireland  
and Caribbean**  
ENERPAC Ltd., P.O. Box 33  
New Romney, TN28 8QF  
United Kingdom  
Tel: +44 01527 598 900  
Fax: +44 01527 585 900

**USA, Latin America  
and Caribbean**  
ENERPAC  
P.O. Box 3241  
6100 N. Baker Road  
Milwaukee, WI 53209 USA  
Tel: +1 262 781 6600  
Fax: +1 262 783 9562

**User inquiries:**  
+1 800 433 2766  
**Distributor inquiries/orders:**  
+1 800 558 0530  
**Technical Inquiries:**  
techservices@enerpac.com

All Enerpac products are guaranteed against defects in workmanship and materials for as long as you own them.

For your nearest authorized Enerpac Service Center, visit us at [www.enerpac.com](http://www.enerpac.com)