

### HV-1000A HOLDING VALVE

L-1666 Rev. 0 1/99

For Date Codes Beginning with the Letter "O"

#### 1.0 IMPORTANT RECEIVING INSTRUCTIONS

Visually inspect all components for shipping damage. Shipping damage is **not** covered by warranty. If shipping damage is found, notify carrier at once. The carrier is responsible for all repair and replacement costs resulting from damage in shipment.

#### SAFETY FIRST

#### 2.0 SAFETY ISSUES



Read all instructions, warnings, and cautions carefully. Follow all safety precautions to avoid personal injury or property damage during system operation. Enerpac cannot be responsible for damage or injury resulting from unsafe product use, lack of maintenance or incorrect product and/or system operation. Contact Enerpac when in doubt as to the safety precautions and operations. If you have never been trained on high-pressure hydraulic safety, consult your distribution or service center for a free Enerpac Hydraulic safety course.

Failure to comply with the following cautions and warnings could cause equipment damage and personal injury.

A **CAUTION** is used to indicate correct operating or maintenance procedures and practices to prevent damage to, or destruction of equipment or other property.

A **WARNING** indicates a potential danger that requires correct procedures or practices to avoid personal injury.

A **DANGER** is only used when your action or lack of action may cause serious injury or even death.



**WARNING:** Wear proper personal protective gear when operating hydraulic equipment.



**WARNING: Stay clear of loads supported by hydraulics.** A cylinder, when used as a load lifting device, should never be used as a load holding device. After the load has been raised or lowered, it must always be blocked mechanically.



**WARNING: USE ONLY RIGID PIECES TO HOLD LOADS.** Carefully select steel or wood blocks that are capable of supporting the load. Never use a hydraulic cylinder as a shim or spacer in any lifting or pressing application.



**DANGER:** To avoid personal injury keep hands and feet away from cylinder and workpiece during operation.



**WARNING: Do not exceed equipment ratings.** Never attempt to lift a load weighing more than the capacity of the cylinder. Overloading causes equipment failure and possible personal injury. The cylinders are designed for a max. pressure of 700 bar. Do not connect a jack or cylinder to a pump with a higher pressure rating.



**Never** set the relief valve to a higher pressure than the maximum rated pressure of the pump. Higher settings may result in equipment damage and/or personal injury.



**WARNING:** The system operating pressure must not exceed the pressure rating of the lowest rated component in the system. Install pressure gauges in the system to monitor operating pressure. It is your window to what is happening in the system.



**CAUTION: Avoid damaging hydraulic hose.** Avoid sharp bends and kinks when routing hydraulic hoses. Using a bent or kinked hose will cause severe back-pressure. Sharp bends and kinks will internally damage the hose leading to premature hose failure.



**Do not** drop heavy objects on hose. A sharp impact may cause internal damage to hose wire strands. Applying pressure to a damaged hose may cause it to rupture.



**IMPORTANT:** Do not lift hydraulic equipment by the hoses or swivel couplers. Use the carrying handle or other means of safe transport.



**CAUTION: Keep hydraulic equipment away from flames and heat.** Excessive heat will soften packings and seals, resulting in fluid leaks. Heat also weakens hose materials and packings. For optimum performance **do not** expose equipment to temperatures of 65°C [150°F] or higher. Protect hoses and cylinders from weld spatter.



**DANGER: Do not handle pressurized hoses.** Escaping oil under pressure can penetrate the skin, causing serious injury. If oil is injected under the skin, see a doctor immediately.



**WARNING: Only use hydraulic cylinders in a coupled system.** Never use a cylinder with unconnected couplers. If the cylinder becomes extremely overloaded, components can fail catastrophically causing severe personal injury.





**WARNING: BE SURE SETUP IS STABLE BEFORE LIFTING LOAD.**

Cylinders should be placed on a flat surface that can support the load. Where applicable, use a cylinder base for added stability. Do not weld or otherwise modify the cylinder to attach a base or other support.



**Avoid** situations where loads are not directly centered on the cylinder plunger. Off-center loads produce considerable strain on cylinders and plungers. In addition, the load may slip or fall, causing potentially dangerous results.



Distribute the load evenly across the entire saddle surface. Always use a saddle to protect the plunger.



**IMPORTANT:** Hydraulic equipment must only be serviced by a qualified hydraulic technician. For repair service, contact the Authorized ENERPAC Service Center in your area. To protect your warranty, use only ENERPAC oil.



**WARNING:** Immediately replace worn or damaged parts by genuine ENERPAC parts. Standard grade parts will break causing personal injury and property damage. ENERPAC parts are designed to fit properly and withstand high loads.

**3.0 DESCRIPTION**

This air pilot holding valve will hold fluid under pressure offering independent control of different branches of the same fixture. Valve works with the VA-42 4-way air valve and a booster. Valve can control the pilot air and the booster in sequence.

**SPECIFICATIONS**


Maximum Hydraulic Pressure . . . . .3,000 psi  
Working Air Pressure Range . . . .14 psi air @ 1,000 psi hydraulic  
Seal Material . . . . .Buna-N

**4.0 INSTALLATION**

1. The unit can be mounted in any direction. Secure the valve to a flat surface with two 1/4" mounting bolts.
2. Connect the pressure line from your pressure source to the hydraulic inlet port.
3. Connect another line from the hydraulic outlet port at the end of the valve to your cylinder or tool.
4. Connect an air line from a directional air valve to the air inlet.

**5.0 OPERATION**

1. Ensure that the directional air valve is positioned so that there is no air pressure going to air pilot port on HV1000A.
2. Operate pressure source. HV1000A should allow system to build hydraulic pressure without leaks.
3. To release hydraulic pressure, apply air pressure to air inlet by switching air directional valve. Pilot ratio is approximately 70 to 1.
4. To begin cycle again, release air pressure from air inlet. Activate pressure source again.



*Figure 1. Example Circuit*

**TROUBLESHOOTING**

SYMPTOM	POSSIBLE CAUSE	SOLUTION
Valve does not hold hydraulic pressure.	External leak.	Check all hydraulic fittings.
	Contamination in valve.	Flush hydraulic section of valve with clean oil. If this does not work, consult service center.
	Air pressure getting to air inlet.	Check air valve for leaks and proper operation.
Valve does not release pressure.	Contamination in valve.	Flush hydraulic section of valve with clean oil. If this does not work, consult service center.
	Air pressure too low.	Check regulator setting.
	Possible air leak.	Check all air connections.

**Australia**

ENERPAC, Applied Power Australia Ltd.  
Block V Unit 3,  
Regents Park Estate,  
391 Park Road  
Regents Park NSW 2143  
(P.O. Box 261) Australia  
Tel: +61 297 438 988  
Fax: +61 297 438 648

**Brazil**

Power Packer do  
Brasil LTDA  
Avenida Ferraz  
Alvim n° 1012  
(09961-550) - Diadema  
S°o Paulo, Brazil  
Tel: +55 11 4051 1188  
Fax: +55 11 4051 3699

**China**

Shanghai Blackhawk  
Machinery Co Ltd  
15H Jinxuan Building  
238 Nandan Road (E)  
Shanghai, 200030, China  
Tel: +86 21 6469 8732  
Fax: +86 21 6469 8721

**France, Greece, Turkey, Middle East,  
Africa**

ENERPAC S.A.  
B.P. 200, Parc d ActivitØs  
du Moulin de Massy  
F-91882 Massy CEDEX (Paris) France  
Tel: +33 01 601 368 68  
Fax: +33 01 692 037 50

**Germany, Denmark, Scandinavia,  
Austria, Switzerland, Eastern  
Europe, CIS**

ENERPAC  
Applied Power GmbH  
P.O. Box 300113  
D-40401 D sseldorf, Germany  
Tel: +49 211 471 490  
Fax: +49 211 471 49 28/40

**Holland, Belgium, Luxembourg,**

ENERPAC B.V.  
Storkstraat 25  
P.O. Box 269  
3900 AG Veenendaal, Holland  
Tel: +31 318 535 911  
Fax: +31 318 535 848  
+31 318 526 645

**Hong Kong**

ENERPAC  
Room 907 Workingberg  
Commercial Building  
41-47 Marble Road,  
North Point  
Tel: +852-2561 6295  
Fax: +852-2561 6772

**India**

ENERPAC  
Hydraulic (India) Pvt Ltd  
Plot No. A-571  
MIDC, TTC Industrial Area  
Mahape-400 701,  
Navi Mumbai, India  
Tel: +91 22 769 47 78  
Fax: +91 22 769 84 73

**Italy**

ENERPAC Applied Power Italiana S.p.A.  
Via Canova 4,  
20094 Corsico (Milano)  
Tel: +39 2 486 111 00  
Fax: +39 2 486 012 88

**Japan**

Applied Power Japan Ltd.  
10-17 Sasame Kita-Machi  
Toda-Shi, Saitama #335, Japan  
Tel: +81 048 421 2311  
Fax: +81 048 421 8949

**Malaysia**

Applied Power Hytec (M) Sdn Bhd 22-1,  
Jalan SS 15/8B  
Subang Jaya, 47500  
P.J. Selangor  
West Malaysia  
Tel: (0203) 73729 23/39/19  
Fax: (0203) 737 29 18

**Mexico**

ENERPAC Applied Power Mexico S.A. de  
C.V.  
Avenida Principal,  
La Paz #100  
Fracc. Industrial La Paz  
42084 Pachuca, Hidalgo  
Tel: +52 771 337 00  
Fax: +52 771 838 00

**Singapore**

Applied Power Asia Pte Ltd  
47 Jalan Pemimpin,  
#01-02 & 01-03  
Sin Cheong Bldg  
Singapore 577200  
Thomson Road,  
P.O. Box 114  
Singapore 915704  
Tel: +65 258 16 77  
Fax: +65 258 28 47

**South Korea**

ENERPAC  
Applied Power Korea Ltd.  
163-12 Dodang-Dong, Choong-Ku,  
Buchun-shi, Kyunggi-Do  
Republic of Korea  
Tel: +82 32 675 08 36  
Fax: +82 32 675 30 02

**Spain, Portugal**

ENERPAC Applied Power International S.A.  
A. Valgrande 14  
Nave 12  
28108 Alcobendas (Madrid), Spain  
Tel: +34 91 661 11 25  
Fax: +34 91 661 47 89

**United Kingdom, Ireland**

ENERPAC Limited  
Unit 3 Colemeadow Road  
North Moons Moat, Redditch  
Worcester B98 9PB  
United Kingdom  
Tel: +44 01527 598 900  
Fax: +44 01527 585 500

**USA, Canada, Latin America and  
Caribbean**

ENERPAC  
6101 N. Baker Road  
Milwaukee, WI 53209 USA  
Tel: +1 414 781 66 00  
Fax: +1 414 781 10 49

**USA**

User inquiries:  
**+1 800 433 2766**  
Distributor inquiries/orders:  
**+1 800 558 0530**

**Canada**

User inquiries:  
**+1 800 426 4129**  
Distributor inquiries/orders:  
**+1 800 426 2284**

**Internet**

[www.enerpac.com](http://www.enerpac.com)

**e-mail**

[info@enerpac.com](mailto:info@enerpac.com)

**All Enerpac products are guaranteed against defects in workmanship and materials for as long as you own them.  
Under this guarantee, free repair or replacement will be made to your satisfaction.**

**For your nearest authorized Enerpac Service Center, visit us at [www.enerpac.com](http://www.enerpac.com)**

Enerpac, a unit of  Tools and Supplies.